

**1 EPOXY USAGE ESTIMATING TABLES<sup>1</sup>**

**TABLE 13 - Holes per FR5MAX-10**

Rod dia.	Hole dia.	Embedment (inch)											
		1	2	3	4	5	6	7	8	9	10	15	20
1/4	5/16	302.1	151.1	100.7	75.5	60.4	50.4	43.2	37.8	33.6	30.2	20.1	15.1
	3/8	178.8	89.4	59.6	44.7	35.8	29.8	25.5	22.4	19.9	17.9	11.9	8.9
3/8	7/16	182.4	91.2	60.8	45.6	36.5	30.4	26.1	22.8	20.3	18.2	12.2	9.1
	1/2	117.1	58.5	39.0	29.3	23.4	19.5	16.7	14.6	13.0	11.7	7.8	5.9
1/2	9/16	131.6	65.8	43.9	32.9	26.3	21.9	18.8	16.5	14.6	13.2	8.8	6.6
	5/8	84.7	42.4	28.2	21.2	16.9	14.1	12.1	10.6	9.4	8.5	5.6	4.2
5/8	11/16	96.2	48.1	32.1	24.1	19.2	16.0	13.7	12.0	10.7	9.6	6.4	4.8
	3/4	65.9	33.0	22.0	16.5	13.2	11.0	9.4	8.2	7.3	6.6	4.4	3.3
3/4	13/16	77.2	38.6	25.7	19.3	15.4	12.9	11.0	9.7	8.6	7.7	5.1	3.9
	7/8	54.5	27.3	18.2	13.6	10.9	9.1	7.8	6.8	6.1	5.5	3.6	2.7
7/8	61/64	67.1	33.5	22.4	16.8	13.4	11.2	9.6	8.4	7.5	6.7	4.5	3.4
	1	44.5	22.3	14.8	11.1	8.9	7.4	6.4	5.6	4.9	4.5	3.0	2.2

**TABLE 15 - Holes per FR5MAX-28**

Rod dia.	Hole dia.	Embedment (inch)											
		1	2	3	4	5	6	7	8	9	10	15	20
1/4	5/16	891.9	446.0	297.3	223.0	178.4	148.7	127.4	111.5	99.1	89.2	59.5	44.6
	3/8	27.9	264.0	176.0	132.0	105.6	88.0	75.4	66.0	58.7	52.8	35.2	26.4
3/8	7/16	538.3	269.2	179.4	134.6	107.7	89.7	76.9	67.3	59.8	53.8	35.9	26.9
	1/2	345.6	172.8	115.2	86.4	69.1	57.6	49.4	43.2	38.4	34.6	23.0	17.3
1/2	9/16	388.5	194.3	129.5	97.1	77.7	64.8	55.5	48.6	43.2	38.9	25.9	19.4
	5/8	250.1	125.0	83.4	62.5	50.0	41.7	35.7	31.3	27.8	25.0	16.7	12.5
5/8	11/16	284.0	142.0	94.7	71.0	56.8	47.3	40.6	35.5	31.6	28.4	18.9	14.2
	3/4	194.6	97.3	64.9	48.7	38.9	32.4	27.8	24.3	21.6	19.5	13.0	9.7
3/4	13/16	228.0	114.0	76.0	57.0	45.6	38.0	32.6	28.5	25.3	22.8	15.2	11.4
	7/8	161.0	80.5	53.7	40.2	32.2	26.8	23.0	20.1	17.9	16.1	10.7	8.0
7/8	61/64	198.0	99.0	66.0	49.5	39.6	33.0	28.3	24.7	22.0	19.8	13.2	9.9
	1	131.5	65.7	43.8	32.9	26.3	21.9	18.8	16.4	14.6	13.1	8.8	6.6
1	1 1/16	143.9	72.0	48.0	36.0	28.8	24.0	20.6	18.0	16.0	14.4	9.6	7.2
	1 1/8	108.1	54.1	36.0	27.0	21.6	18.0	15.4	13.5	12.0	10.8	7.2	5.4
1 1/4	1 3/8	83.7	41.9	27.9	20.9	16.7	14.0	12.0	10.5	9.3	8.4	5.6	4.2
	1 1/2	55.0	27.5	18.3	13.8	11.0	9.2	7.9	6.9	6.1	5.5	3.7	2.8
Rebar size													
10M	9/16	391.6	195.8	130.5	97.9	78.3	65.3	55.9	49.0	43.5	39.2	26.1	19.6
15M	3/4	268.4	134.2	89.5	67.1	53.7	44.7	38.3	33.6	29.8	26.8	17.9	13.4
20M	61/64	173.8	86.9	57.9	43.4	34.8	29.0	24.8	21.7	19.3	17.4	11.6	8.7
25M	1 1/4	84.7	42.3	28.2	21.2	16.9	14.1	12.1	10.6	9.4	8.5	5.6	4.2
30M	1 1/2	58.8	29.4	19.6	14.7	11.8	9.8	8.4	7.3	6.5	5.9	3.9	2.9
35M	1 3/4	48.3	24.2	16.1	12.1	9.7	8.1	6.9	6.0	5.4	4.8	3.2	2.4

<sup>1</sup>For correct epoxy usage, add 20% waste (multiply the tabulated number by 0.80)

**Click here to view complete technical data for FR5MAX**